



SECURITY DOOR CONTROLS

3580 Willow Lane, Westlake Village, CA 91361-4921 • (805) 494-0622 • Fax: (805) 494-8861
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION/PROGRAMMING INSTRUCTIONS 950 ENTRYCHECK®



The EntryCheck® incorporates all the logic necessary to control a single door. All Unit Programming is performed by using the built-in keypad. Proximity cards, key fobs and PIN entries can be added and deleted with the keypad using the master code or programming card. The lock relay and auxiliary relay outputs can be set for 1-99 seconds.

CHOICE OF ENTRY MODE

The SDC EntryCheck® provides a choice of three programmable entry modes:

- Proximity Reader Only
- Proximity Reader or PIN Code
- Proximity Reader and PIN Code

WALL OR GLASS MOUNTED

The weather resistant unit is easily surface mounted to the wall either inside or outside. An optional glass mounting kit is available. When the EntryCheck® is mounted to the interior side of a glass sidelight or store front, the proximity reader may be activated from the exterior through the glass.

FEATURES

- Up to 500 Cards and/or PIN Codes
- Choice of three entry modes:
Proximity Reader only
Proximity Reader or PIN Code
Proximity Reader and PIN Code
- Up to 6" inch/152 mm reader range
- Add / change / delete cards and PINs
- Programmable door unlock time from 1 - 99 seconds
- Tamper alarm and reader/PIN lockout
- Request-To-Exit input
- Two outputs, lock relay and auxiliary relay
- LED and audible tone for operation ease.
- Weather resistant

ORDERING INFORMATION

950C Prox / PIN reader w/10 cards

950K Prox / PIN reader w/10 key fobs

C10 Ten SDC prox cards

K10 Ten SDC key fobs

950GL-KIT Interior glass mounting kit

TR12 12VDC Plug-in power supply with AC ground and two fused outputs. Access control output: 150 mA filtered / regulated. Lock output: 780 mA filtered.

USER INFORMATION

To open door using card and PIN
Present Card (LED flashing *red*)
Enter PIN (LED *green*)

To open door using PIN only
Enter PIN number (LED *green*)

To open door using card only
Present card to reader (LED *green*)

Caution: Master card must be programmed prior to any other programming.

PROGRAM MASTER CARD

Apply power.(LED flashing *yellow*)

Enter **★ 000000 ★**

Enter **2 ★** (LED flashing *green*).

Present Master card to reader and
Remove (1 beep).

Enter **#** (6 beeps).

PROGRAM UNLOCK TIME (Default is 1 sec)

Enter **★**.

Present Master card to reader and
Enter **★** Remove (6 beeps).

Enter **4 ★** (LED flashing *green*).

Enter delay on relock time
(i.e. 03 = 3 sec.). Default is 1 sec.

Enter **★** (1 beep, *green* LED).

Enter **#** (6 beeps).

Note: 00 = Toggle

PROGRAMMING ENTRY MODE

Choose the mode of entry you require.

0 = CARD and PIN (Default)

1 = CARD Only

2 = CARD or PIN

Enter **★**.Present Master card to reader

Enter **★** Remove (6 beeps).

Enter **5 ★** (LED flashing *green*).

Enter 0, 1 or 2.

Enter **★ #** (6 beeps).

NOTE:

- When programming a new card you must enter **★** first to enter the programming mode and present the Master Card.
- PIN needs to be programmed for each new card even if CARD only entry mode is chosen.
- Yellow LED flashing may also be viewed as an alternating *red* and *green* LED.
- The **#** key exits the programming mode (LED flashing Yellow).
- Keep a log of each card issued. See sample log below.

PROGRAMMING ONE CARD & PIN

Enter **★** (1 beep, *green* LED).

Present Master card to reader and Enter **★**
Remove.(6 beeps)

Enter **★ 1 ★** (LED flashing *green*).

Enter **01 ★ 001 ★** (delayed 1 beep).

Present new card to reader and remove (1 beep).

Key in any 4 digit PIN for new card.

Enter **#** (6 beeps).

Repeat above for every card to be entered.

CARD BATCH PROGRAMMING

Note: PIN will be the same for all cards
programmed in the batch mode.

Enter **★** (1 beep, *green* LED).

Present Master card to reader and Enter **★**
Remove (6 beeps, *red* & *green* flashing).

Enter **1 ★** (1 beep, LED flashing *green*).

Enter number of cards to be programmed
(01-99)

Enter **★** (1 beep, *green* LED).

Enter starting user number (001-499)

Enter **★** (1 beep, *green* LED).

Present first sequential card.

Enter 4 digit PIN number (1 beep, *red* & *green* flashing LED)

Enter **#** to exit. (6 beeps and Flashing
Yellow LED)

DELETE CARD

Enter **★**. Present Master card to
reader and Enter **★**
Remove (6 beeps, *red* & *green* flash-
ing).

Enter **7 ★** (LED flashing *green*).

Present card to be deleted to reader
and remove (1 beep).

Enter **#** (6 beeps).

OR

Enter **★** Present Master card to
reader and Enter **★** Remove (6
beeps).

Enter **7 ★** (LED flashing *green*).

Key in last six numbers located on
card to be deleted.

Enter **★** (1 beep).

Enter **#** (6 beeps).

RESET TO FACTORY DEFAULTS & DELETE MASTER CARD

Disconnect power.

While depressing both the **★** & **#**
keys, apply power. The LED will flash
green and then after a few seconds
will turn *red*. This resets the master
code to the default '000000'. To erase
all user cards and settings as well as
the master code, continue depressing
the **★** & **#** keys until the *red* LED
goes out.

Remove power

Release the **★** & **#** keys

Wait 5 seconds

Reapply power.

ADMINISTRATIVE LOG (sample)

ENTRY MODE SET FOR

0 ☐ CARD and PIN


1 ☐ CARD Only

2 ☐ CARD or PIN

Master Card Number _____

CARD NUMBER	PIN NUMBER	USER I.D.	DATE ISSUED	DATE DELETED

PCB front view

1  3 N/C contact RL1 (magnet)
1 3 N/O contact RL1

Do not use a switching power supply. The interference radiation may disturb the reading of the badges.



LEGEND

AT1	Anti-Tamper Switch
ST2	Jumper for Relay 1
RL1	Door Relay
RL2	Alarm Relay
V1	Varistor
PB1	REX Push Button

[illegible]

O:\INS\INST-950.qxd REV D 0403 Page 3

950 ENTRYCHECK® MASTER CARD ENROLLMENT TROUBLESHOOTING GUIDE

WHAT IS A MASTER CARD

The master card is the one card used to access the programming mode of the 950. Once enrolled, it can be used in place of the master code at time of programming. Although the card is the same physical type of card as a user card, the 950 treats it in a different way. When you enroll a card as the master card, the 950 not only reads the serial number of the card (like it does when it enrolls a user card) but also programs a special code into a memory chip located on the card itself. When the card is presented to the 950, both the serial number and the special code are read for validation.

MASTER CARD ENROLLMENT PROBLEMS

If programmed, the program card will no longer function as a user card or as a master card for another unit without first erasing the card's internal memory chip. They usually come from the manufacturer fully erased and ready to enroll as either a master or user card. Occasionally a card may need to be erased again before it will be accepted as a master card at time of enrollment. This is the procedure:

RESET THE 950 TO FACTORY DEFAULT SETTINGS

Disconnect Power.

While depressing both the * & # keys, apply power. The LED will flash green and then after a few seconds will turn red. This resets the master code to the default '000000'. To erase all user cards and settings as well as the master code, continue depressing the * & # keys until the red LED goes out.

Remove power

Release the * & # keys

Wait 5 seconds

Reapply power.

ERASE THE CARD

Apply Power.

Enter * 000000 * (the unit is now in programming mode)

Enter 7*. (LED flashes green)

Present the card to be erased and remove (1 beep).

Enter #. (6 beeps and the unit is now out of programming mode again).

The card is now erased and ready to be enrolled as a master card.