



SECURITY DOOR CONTROLS

3580 Willow Lane, Westlake Village, CA 91361-4921 • (805) 494-0622 • Fax: (805) 494-8861
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION INSTRUCTIONS/TEMPLATE 80 SERIES ELECTRIC LOCKS

1. Mark and drill as follows: Holes 1, 2 and 3 for #14 sheet metal screws or 1/4 - 20 machine screws.
Hole 4 – 3/8" diameter for wire.
Block strike: Holes 5 and 6 or 12 and 13 for 1/4 - 20 machine screw or #14 sheet metal screw.
2. Tap holes as required.
3. Remove housing cover and mount lock and strike.
4. Attach power leads. Check alignment of bolt and strike. There should be no binding. Leading part of strike should be 1/8" away from the lock 1/8" is maximum distance. If this is correct, tighten mounting screws.
5. Check lock operation for any last adjustments.
6. Install housing.

SPECIFICATIONS

DIMENSIONS: 2" x 2" x 6"

FINISH: US28 standard (dark duranodic optional)



BOLT: 180 and 280 series 5/8" diameter 1/2" throw



SOLENOID: 180 series, power lock, continuous duty
280 series, power unlock, continuous duty
24 VAC, 0.5 Amp; 24 VDC, 0.5 Amp; 12VDC, 1 Amp

180 Series Dual Voltage (Fail Safe):

7.2 Watts – 12VDC @ .9 Amp

7.2 Watts – 24VDC @ .45 Amp





FOLD ON DOTTED LINE AND HOLD AGAINST STOP



-6 BOLT POSITION SENSOR

-9 DOOR POSITION SENSOR

SPDT .25 AMP

RED - N.C.
WHT - COM
BLU - N.O.

FOLD ON DOTTED LINE AND HOLD AGAINST STOP

