



SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION INSTRUCTIONS 482A4U SQUARE PUSH PLATE SWITCH, PUSH TO OPEN, BLUE INFILL – 4-1/2" SPDT



BLUE INFILL

Specifications

Physical Size: 4-1/2"sq x 1-15/32"D
Switch mounts to a Single Gang (2"x4") or Double Gang (4"x4")
electrical box


Contact Type: SPDT Momentary
Contact Rating: 2 Amp @48VDC
15 Amp @125/250VAC

Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION INSTRUCTIONS 482A4RU ROUND PUSH PLATE SWITCH, PUSH TO OPEN – 4-1/2" SPDT



Specifications


Physical Size: 4-1/2" Dia x 1-15/32"D
Switch mounts to a Single Gang (2"x4") or Double Gang (4"x4")
electrical box

Contact Type: SPDT
Contact Rating: 2 Amp @48VDC
15 Amp @125/250VAC

SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION INSTRUCTIONS 480-4SBB / 480-6SBB SURFACE MOUNT BOX w/BATTERY COMPARTMENT



BLACK ABS MATERIAL BOX EQUIPPED FOR WIRED OR WIRELESS APPLICATION. USED WITH 4-1/2" SQ. AND 6" SQ. SWITCHES

480-4SSB / 480-6SBB MOUNTING INSTRUCTIONS

(HARD WIRED and WIRELESS)

- 1) Break out the battery compartment access cover from the back of the box and install it into the open area in the side wall located at the bottom of the box, as it will hang on the wall.

When the access cover is in the closed position, the slot in the cover will face out and be closest to the switch.

When installed correctly, the door slides smoothly and will be held in place by the mounting plate.


If needed, drill a small weep hole in the bottom of the box (as it hangs) to allow moisture to evaporate.

- 2) Use appropriate screws (not supplied) to mount the box to the wall surface at the 4 open mounting hole positions.


- 3) If you are using a wireless transmitter, attach the transmitter to the back of the box using the included double sided tape. Connect the battery terminals to the battery and install into the battery compartment.

Program the transmitter to match the receiver.

- 4) For either Hard-wired or Wireless setups, connect the lead wires to the switch at the N/O and COM contacts.



- 5) Fit the 6-32 x 5/8" socket cap screws from the switch parts bag into the 4 integral mounting pins located at the upper and lower 2-gang positions.




- 6) Hang the wall switch onto the socket cap screws and tighten down with the allen wrenches provided in the parts bag or with the handle grip allen wrenches. Alternate the tightening of the screws a few turns at a time each from the top to bottom.

SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

INSTALLATION INSTRUCTIONS 480-4RFB / 480-4RSB & 480-6RFB / 480-6RSB SURFACE/FLUSH MOUNT BOX FOR 4-1/2" & 6" DIAMETER SWITCHES

CROSS SECTIONAL VIEWS



Parts included with mounting boxes: >Black ABS surface or flush mount box >Transmitter mounting pins >9V battery mounting clip >Mounting instructions >Weather resistant gasket (optional)

480-4RSB & 480-6RSB SURFACE MOUNT: Hollow Wall or Solid Wall (illustration #1) 1] Drill pilot holes in mounting box (placement indications are in box). 2] Drill pilot holes in mounting surface. 3] Insert appropriate fastener (screw, toggle, etc.) through box and into mounting surface; tighten. 4] Complete installation of switch.

480-4RFB & 480-6RFB FLUSH MOUNT: Hollow Wall ONLY (illustration #2) 1] Cut access hole into mounting surface: 5-1/2" dia. for 4-1/2" round box – 6-1/2" dia. for 6" round box. 2] Insert box into the hole. 3] Utilize the two phillips head screws to tighten silver hanger to the mounting surface. 4] Complete installation of the switch.

Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com


480-4RSB

5" Diameter x 2-1/8" Height
(127mm x 55mm)
1-7/8" inside depth (48mm)
Used with 4-1/2" round switches

480-6RSB


6-7/16" Diameter x 2-1/8" Height
(164mm x 55mm)
1-7/8" inside depth (48mm)
Used with 6" round switches

For flush mount use 480-4RFB / 480-6RFB



- Surface mount black ABS material for wireless or hard-wired applications
- Repositionable mounting pins for transmitter placement
- Weather resistant gasket (optional)

480-4RG used with 480-4RSB
480-6RG used with 480-6RSB




480-4RFB

6-3/8" Diameter x 2-1/8" Height
(162mm x 55mm)
1-7/8" inside depth (48mm)
Used with 4-1/2" round switches

480-6RFB


7-3/4" Diameter x 2-1/8" Height
(197mm x 55mm)
1-7/8" inside depth (48mm)
Used with 6" round switches

For surface mount use 480-4RSB / 480-6RSB



- Mounting bracket for hollow walls.
- Flush mount black ABS material for wireless or hard-wired applications;
Wireless use requires RF Transparent walls.
- Repositionable mounting pins for transmitter placement.
- Weather resistant gasket (optional)

480-4RG used with 480-4RSB
480-6RG used with 480-6RSB



SDC Security Door Controls


801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

PROGRAMMING INSTRUCTIONS 400W1-433 Transmitter, 433 Frequency

Programming -

NOTE: The 400W1-433 Transmitter is only compatible with the 400RC433 Receiver.

- 1) Attach battery to the 400W1-433 transmitter.
- 2) Push P1 on the Receiver 1 channel 433 until you hear a beep, then touch the black flagged wires together and hold until the receiver beeps again. The 400W1-433 will then be programmed into the receiver.



Troubleshooting -

Problem

A) The receiver does not receive the transmitter signal and the transmitter LED will not light up.

Solution
Change the battery

B) Operation is very weak or sporadic

Change the battery or check the wiring on the transmitter or receiver to make sure wires are secure and not pinched.

3) Attach quick connects to switch. Twist wires from the switch and transmitter together and insert into the gel connector and crimp.

Technical Specifications -

Operating Frequency – 433 MHz

Battery - 9 Volt DC

Operating Temperature - -20 C -100 F


Type – 433TSPWIK
FCC IS: SU433TSP4K

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1) This device may not cause harmful interference, and

2) This device must accept interference received, including interference that may cause undesired operation.



ATTACH QUICK CONNECTS TO SWITCH,
 TWIST WIRES FOR TRANSMITTER AND SWITCH
 TOGETHER AS SHOWN. INSERT INTO GEL
 CONNECTORS AND CRIMP.

SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 •
www.sdcsecurity.com • E-mail: service@sdsecurity.com

PROGRAMMING INSTRUCTIONS for the 400RC433 RECEIVER, ONE CHANNEL



REC 1 CHAN 433

1 - DESCRIPTION

The Nano Receiver is designed to control automatic closing systems and anti-burglar systems, thanks to it's very high security coding system (KeeLoq® Hopping code).

The operating frequency is among European harmonized frequencies; the product fully complies with the EMC European Regulations (CA).


The code sent by the transmitter changes at every activation, avoiding any scanning and copying risk. A special algorithm allows for synchronization of transmitter and receiver.

The receiver has 1 output relay with NO contacts, and can be connected to many types of mechanics (gate, garage door, rolling shutters,, awnings, anti-burglar appliances, etc.).

All the receivers of this range can store into the EEPROM a serial number, a manufacturer key and a synchronization algorithm of more transmitters. The programming can be done in a self-learning mode by means of one button.

The housing protection allows indoor installations.



This appliance fully complies with the European Regulations 89/336/EEC, 73/23/EEC, EN 60950-1 and FCC Part 15.



2 – TECHNICAL SPECIFICATIONS

Receiver type	Superheterodyne
Carrier frequency	433.92 MHz
Local oscillator frequency	6.6128 MHz
Demodulation	AM/ASK
Local oscillator	VCO / PLL
Channel width	> 25 KHz
Intermediate frequency	10.7 MHz
Input sensitivity	-115 dBm
Local oscillator spurious emissions	< -57dBm
Input load	50 Ohm
Power supply	12 / 24 VAC/DC
Max applicable power	12 VA
Relay number	1
Contacts	C-NO
Memory capacity	85 user codes
TX security code	Rolling code
Max code combination number	2
Operating Temperature	-20 / +70 deg C
Housing protection	IP2X
Overall dimensions (mm)	50 x 32 x 20

3 – LAYOUT AND CONNECTIONS




Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

4 – TRANSMITTER PROGRAMMING

4.1 Using P1


- 1) Keep P1 pressed down until the buzzer emits a short beep (Fig 3);
- 2) Push the key of the transmitter to program, and vary the beep of the receiver;
- 3) At this point, the receiver waits for more transmitters – 5 seconds after the last transmitter is programmed, the receiver makes a beep and the procedure ends.



4.1 Using P1

With this procedure it is possible to program the transmitters without accessing P1 (Fig 4)

- 1) Push simultaneously the keys A & B of the transmitter until it beeps.
- 2) Release and push the A key until the next beep of the buzzer (memory opening);
- 3) Release A and push the key of the transmitter to program (A or B) until the beep of the buzzer (memory closing).



NOTE: The Programming of a new transmitter can be done only using a transmitter already programmed. Use the transmitter already programmed to open the memory (Steps 1 & 2). Complete the procedure by pressing the key of the new transmitter to program.

5 – MEMORY FULL

If the memory is full when you try to program a new transmitter, the buzzer beeps three times.

6 – MEMORY ERASURE

6.1 Single Transmitter

- 1) Keep P1 pressed down until the buzzer beeps, then release it.
- 2) Push the key of the transmitter to delete until the buzzer beeps.

6.2 Full Memory Erasure

- 1) Push P1 until the buzzer beeps, then release it.
- 2) Release P1 and push it again until the buzzer beeps 3 times. At this point, the memory has been completely erased.

7 – ENABLING/DISABLING THE ACTIVATION BEEP

To program the receiver to make a beep at each relay activation, follow this procedure: (Fig 5)

- 1) Simultaneously press the A & B keys of a previously programmed transmitter.
- 2) Release and press the B key of the transmitter to enable the beep. to disable the beep, repeat the above procedure.

