


## INSTALLATION INSTRUCTIONS LR100DHK DESIGN HARDWARE ELECTRIC LATCH RETRACTION KIT MODELS: 1000R & 1000V

**<u>Retrofit Installation Note:</u>** 42" or 48" Exit Devices that have been modified to fit a 36" or smaller opening, may not have the required space to fit the standard E.L.R. Assembly. Always verify the distance from the end of the touchpad to the end rail, and if necessary, consult with the factory for appropriate selection.



## **NOTE: Retro-Fitting Vertical Rod Exit Devices**

Before retro-fitting an E.L.R. Assembly into a Vertical Rod Exit Device, the following must be done to ensure proper alignment. Disconnect the Vertical Rods from the Exit Device. Install the E.L.R. Assembly as shown above. Once the E.L.R. is properly installed energize it so that the Exit Device Push Pad is dogged down, by doing so it will allow for proper alignment for the Vertical Rods. Finally, reconnect the Vertical Rods to the Exit Device and make the proper adjustments.