



SECURITY DOOR CONTROLS ■ WWW.SDCSECURITY.COM
 801 Avenida Acaso, Camarillo, CA 93012
 [t] 800.413.8783 ■ 805.494.0622 ■ E-mail: service@sdsecurity.com

TEMPLATE-S6203

Devices covered by this template:
Panic / Fire SVR Exit Device and 03 Nightlatch Trim.

THIS SIDE UP FOR LHR DOOR

PLACE THIS SIDE ON FRAME STOP

PLACE THIS SIDE ON DOOR

FRAME STOP

DOOR

THIS SIDE UP FOR RHR DOOR

FOLD HERE

CAUTION
 DO NOT USE DOOR EDGE

FOLD HERE


(4x) DEVICE MOUNTING HOLES

METAL: DRILL / TAP FOR 1/4"-20 MACHINE SCREWS

WOOD: PRE-DRILL 1/8" HOLES.

SEXBOLTS: DRILL 5/16" CLEARANCE HOLES ON PUSH SIDE,
 3/8" HOLES ON PULL SIDE.

TRIM: DRILL 5/16" CLEARANCE HOLES ON PUSH SIDE,
 15/32" HOLES ON PULL SIDE.



5/8" CLEARANCE HOLE FOR RIM CYLINDER OR TRIM. NOT
 REQUIRED FOR EXIT ONLY. FOR TRIM INSTALL REFER TO
 THE CORRELATING INSTRUCTIONS / TEMPLATE.

(2x) END CAP BRACKET HOLES

METAL: DRILL / TAP FOR 1/4"-20
 MACHINE SCREWS.

WOOD: PRE-DRILL 1/8" HOLES.

SEXBOLTS: DRILL 5/16" CLEARANCE
 HOLES ON PUSH SIDE, 3/8" ON
 PULL SIDE.

OPTIONAL 1/2" dia.
 WIRE RUN

AFTER EXIT DEVICE IS CUT AND
 MOUNTED, INSTALL END CAP
 BRACKET CENTERED ON DEVICE CL

Watch for special
 mounting height
 requirements

FINISHED FLOOR



**TOP LATCH
TEMPLATE**

(3x) Top Strike Holes

METAL: DRILL / TAP FOR 1/4-20
MACHINE SCREWS

WOOD: 1/8" PILOT DRILL

PLACE THIS SIDE ON
TOP FRAME.

PLACE THIS SIDE ON
DOOR SURFACE SIDE


(2x) TOP LATCH HOLES

METAL: DRILL / TAP FOR 1/4-20"
MACHINE SCREWS

WOOD: PRE-DRILL 1/8" HOLES

LHR DOOR EDGE OR STOP FACE

RHR DOOR EDGE OR STOP FACE



**BOTTOM LATCH
TEMPLATE**

(NOT REQUIRED FOR LBR DEVICE)


(2x) TOP LATCH HOLES

METAL: DRILL / TAP FOR 1/4-20"
MACHINE SCREWS

WOOD: PRE-DRILL 1/8" HOLES

LHR DOOR EDGE OR STOP FACE

RHR DOOR EDGE OR STOP FACE



CUT HERE TO SEPARATE TOP TEMPLATE AND BOTTOM TEMPLATE

**TEMP-EK03_GK03
03 NIGHTLATCH TRIM**

