




801 Avenida Acaso, Camarillo, Ca. 93012  
 • (805) 494-0622 • Fax: (805) 494-8861  
 www.sdcsecurity.com • E-mail: service@sdsecurity.com

## Security Door Controls


TEMPLATE-S6200, TEMP-S6200-EKE03-GKE03  
 SURFACE MOUNT VERTICAL ROD




1. Draw a centerline horizontally across the door, 40" (1016mm) from bottom of door.
2. Draw a vertical centerline 2-7/16" (62mm) from edge of door.
3. Select the appropriate side of both templates. (1 & 2). Your door handing will determine the appropriate side, either (LHR) or (RHR).
4. Using dimensions indicated on templates 1 & 2, locate and mark the center of the required holes.
5. Drill holes as indicated by their designated letter.
6. If using an exterior trim, refer to the template with trim to further prepare door.

**A** **METAL – Panic Rated:** Drill/Tap for 1/4-20 machine screws (sexbolts recommended).  
**METAL – Fire Rated:** Sexbolts required.  
**SEXBOLTS:** Drill 3/8" (9.5mm) clearance holes on Push and Pull Sides.  
**WOOD:** Pre-Drill 1/8" (3mm) hole.

**B** **ACTUATING SHAFT HOLE:** Drill 1/2" thru hole.




Dimension Guide for – RHR (Right Hand Reverse door) Template 2






1. Draw a centerline horizontally across the door, 40" (1016mm) from bottom of door.
2. Draw a vertical centerline 2-7/16" (62mm) from edge of door.
3. Select the appropriate side of both templates. (1 & 2). Your door handing will determine the appropriate side, either (LHR) or (RHR).
4. Using dimensions indicated on templates 1 & 2, locate and mark the center of the required holes.
5. Drill holes as indicated by their designated letter.
6. If using an exterior trim, refer to the template with trim to further prepare door.

**METAL – Panic Rated:** Drill/Tap for 1/4-20 machine screws (sexbolts recommended).  
**METAL – Fire Rated:** Sexbolts required.  
**SEXBOLTS:** Drill 3/8" (9.5mm) clearance holes on Push and Pull Sides.  
**WOOD:** Pre-Drill 1/8" (3mm) hole.

**ACTUATING SHAFT HOLE:** Drill 1/2" thru hole.







**TEMPLATE  
 ELECTRIC TRIM  
 EKE03/GKE03 SERIES**

**Simple Instructions:**

1. Using a 1/2" drill at locations A, B, C & D, drill four holes through to accept the four escutcheon standoffs.
2. Drill or saw a 1.50" dia hole at location E.
3. Fasten the supplied mounting screws into the hex standoffs on the trim, from the inside of the door. The four screws must go through the chassis of the exit device.
4. Install cylinder. See installation instructions of Rim Exit Device.

**NOTE:**

1. For single doors and double doors with mullion, use the backset dimension of 2-7/16" to **FACE OF STOP**.
2. Dimensional drawing, not to scale.

**ELECTRIC TRIM WIRES  
 MUST BE WIRED THROUGH THE  
 DOOR RACEWAY AND NOT THROUGH  
 THE EXIT DEVICE**

